43-733add.fm Page 1 Friday, October 22, 1999 10:41 AM

ADDENDUM
TAD-733
900 MHz Digital Spread Spectrum Cordless Telephone and Answering System with Headset Jack
Cat. No. 43-733

Follow these instructions to set your phone's ringer volume and ringer tone.

SETTING THE RINGER'S VOLUME

To adjust the ringer's volume when the phone is not in use, press **VOLUME** ▲ or ▼ on the handset.

CHECKING/SETTING THE RINGER TONE

You can set the TAD-733's handset to sound any of four ringer types. The handset is preset to use ringer tone 1. To change or hear the different tones, press **FLASH** then **1**, **2**, **3**, or **4** when the phone is not in use and **RINGER** is set to **ON**. (The tone you hear corresponds to the last number button pressed.)

© 1999 Tandy Corporation.
All Rights Reserved.
RadioShack is a registered trademark used by Tandy Corporation.

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

11A99

Printed in China